



HOUSE OF RENTAL

Skokie
5115 Church St.
Skokie, IL 60077
Tel. (847) 677-2010
Fax (847) 677-3790

Wheeling
318 N. Milwaukee.
Wheeling, IL 60090
Tel. (847) 537-2255
Fax (847) 537-4599

Glennview
1766 Waukegan Rd.
Glennview IL 60025
Tel. (847) 657-9020
Fax (847) 657-9099

Make all the connections with the LCD & computer turned off.

Startup

Once all connections have been made, turn the LCD projector on and use the INPUT key on top of the LCD projector to make sure it is on RGB(computer cable) is selected. Next turn on your computer. The screen should come up automatically.

If the screen does not come up- Look on the top of the keyboard (the function keys) for a icon that looks like a monitor. At the same time hold the function key (at the bottom left of the keyboard) and hit the key at the top that has a monitor icon on it. The screen should come up automatically.

For computer video

Connect VGA cable from laptop computer out to input1 of LCD.

For computer audio

Connect computer audio cable from headphones out of laptop to the sound system

For video from a VCR

Connect RCA cable from video out of VCR to video input on LCD.

For audio from a VCR

Connect RCA cable for audio out to audio input to the sound system.

Shutdown the projector

When finished turn the LCD to standby (top buttonLCD) and wait for the cooling fan to turn the light green. Then shut off the side power switch and unplug all of your connections and pack the LCD away.