



Money Machine



1. Assemble two Squares using 4 pipes and 4 corner fittings for each



2. Insert pipes into each corner of one square and the remaining pipes into the four corners of the other square.



3. Turn the two cubes onto their sides and slide them together.



4. Attach the vinyl booth while the unit is lying on its side. Then tip it into its up-right position.

Safety Instructions

1. Do not use the blower near water, or plug it in if it is wet.
2. **NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!**
3. Use caution when setting up or taking down the game. Once the bolts are loosened the sections of tubing can come apart and fall down causing injury.
4. Be sure players wear the safety goggles inside the booth. Keep spectators away from the blower.
5. Secure power cord to avoid a trip-hazard.

Suggested Rules

1. Players must remove shoes and put on goggles before entering.
2. Player must not begin collecting bills until the operator says, "Go!"
3. The player must stop collecting bills when the operator says, "Stop!"
4. When the operator turns on the blower, he/she should allow a few seconds for the bills to start circulating before giving the "go" signal.
5. The player must remove the bills from the air. He/She may not take bills off of the floor, ceiling, walls or off of their own body.
6. The operator may or may not supply a collection pouch for the bills, depending on the amount of bills they wish to give away. (Obviously, if the play can only keep what he/she can hold in their hands, fewer bills will be awarded.)
7. The operator may use real cash, play money, a mixture of real/play money, coupons, tickets, etc.
8. Crumpled bills circulate better than crisp or flat bills. Therefore, you may wish to keep crumpled bills inside the unit and replace them with an equal amount of fresh ones for each player as they exit.