



Skokie 847-677-2010 Glenview 847-657-9020 Wheeling 847-537-2255

Popcorn machine

Electrical requirements: This machine is designed to operate on a 120 volt/ 15 amp/ single-phase outlet. Make sure the popper is on a **dedicated line**, and that **no** other **appliances** are **on the same circuit**. If you choose to use an extension cord it is **“use at your own risk” 10 gauge extension cord 25ft** is what we suggest

Operating Instructions

Light and warmer switch: Turns on the heat to the bottom corn pan and heat light.

Kettle motor switch: turns the motor which drives kettle agitator shaft.

Kettle heat switch: Turns on the heat element

*Turn “Kettle Heat” Switch and “Kettle motor &Exhaust” switch “ON”

How to make Popcorn

Mega-Pop: (A sale item that we carry) Allow kettle to **heat 3-4 minutes**, when starting a cold machine. Cut oil packet along top edge and squeeze oil into kettle. As soon as oil melts, cut corn packet and pour corn and salt into kettle. Close lid. **Empty** kettle **immediately** after popping stops.

*Always do a test with about 3 kernels.

If using your own popcorn and oil:

Do this at your own risk!!!!

Corn- 8oz

Oil- 2.6 oz

Flavacol- 1 Tablespoon