



Skokie 847-677-2010 Glenview 847-657-9020 Wheeling 847-537-2255

Sno-Kone Machine



Electrical Requirements:

- If you choose to use an extension cord it is **“use at your own risk” 10 gauge** extension cord and **25ft** is what we suggest.

- 120 VAC, 60Hz. 15 Amp Fused Circuit

How to Operate:

1. Load Hopper with ice.
2. Close pusher handle
3. Turn power switch to the **“ON”** position.
4. Apply downward pressure on pusher handle while holding red momentary shave ice switch.
5. Do not lift the pusher handle until the motor is off and the shaver head is stopped

Warning:

- Never put fingers or any object into the shaver body, while motor is running. **Serious injury may occur!**
- This machine is **NOT** to be operated by minors.