



Skokie 847-677-2010

Glenview 847-657-9020

Wheeling 847-537-2255

Hot Box

HOW TO USE THE STERNO CABINET:

1. Cabinet operates with three (3) standard size 7-oz. cans of fuel for an overall average holding temperature of 170°F (depending on location in cabinet):
 - (a) Top = 156°F
 - (b) Middle = 169°F
 - (c) Bottom = 209°F
2. Cabinets hold hot precooked foods. It is NOT to be used as an oven.
3. Top and bottom vents in door MUST be open for proper air flow.
4. How to hold with added humidity:
 - (a) Place a 12" x 20" hotel pan, approximately half full of hot water, on an 18" x 26" sheet pan.
 - (b) Slide sheet pan into cabinet, two shelf spaces above the flame.
 - (c) Do not block air flow at rear of cabinet.
5. Three (3) 7-oz. cans of gelatin fuel will burn for approximately two (2) hours. Exact length of time canned fuel will burn is determined by brand and type of fuel.

HOW TO CLEAN THE UNIT:

- Wipe up spills as soon as possible.
- Clean regularly to avoid heavy dirt build-up.

Hints:

1. Use the mildest cleaning procedure that will do the job.
2. Always rub in the direction of polish lines to avoid scratching the surface.
3. Use only soft cloth, sponge, fibrous brushes, plastic, or stainless steel pads for cleaning and scouring.
4. Rinse thoroughly with fresh water after every cleaning operation.
5. Always wipe dry to avoid water marks.

| SOIL | CLEANER | METHOD |
|-----------------------------|--|--|
| DIRT | Mild detergent* and hot water, or mild abrasive cleaner. | 1. Use soft, damp cloth. 2. Rinse with hot water. 3. Wipe dry. |
| | Steam (no strong alkaline additive) | 1. Rinse after steam cleaning. 2. Wipe dry. |
| FINGERPRINTS, GREASE OIL | Chemical oven cleaner for aluminum | Follow oven cleaner manufacturer's directions. |
| | Mild abrasive cleaner; oily or waxy cleaner. | Apply with soft, clean cloth. |
| WATER SPOTS | Mild abrasive cleaner. | Wipe with damp cloth. |

* Mild detergents include soaps and non-abrasive cleaners.